


Models:

BX3C
2PWN



Classic Ducted Gas Heater

Installation Manual

brivis
Rinnai

This appliance must be installed in accordance with:

- Manufacturer's Installation Instructions
- Current AS/NZS 3000, AS/NZS 5601, AS/NZS 5141
- AS 4254, HB 276-2004
- Local Regulations and Municipal Building Codes including local OH&S requirements

This appliance must be installed, maintained and removed only by an Authorised Person.

For continued safety of this appliance it must be installed and maintained in accordance with the manufacturer's instructions.



Table of Contents

Warnings and Important Information	5
1. Scope	7
1.1 Installer Due Diligence for Changeovers	7
Definitions.....	7
Disclaimer.....	8
2. General Product Guidelines	9
2.1 Application and Sizing.....	9
2.2 Inspection.....	9
2.3 Unpacking the Heater	9
2.4 Unloading or Lifting the Heater	9
2.5 Service Connection Guidelines.....	10
2.5.1 Gas Inlet Connection	10
2.5.2 Electrical Power Supply	10
2.6 Installation of Duct Connection Pops	10
2.7 Heater Positioning	10
2.8 Installation of External Heaters	10
2.9 Installation of Internal Heaters	11
2.10 Installation of Internal Heaters in a room, enclosure, residential garage or plant room.....	11
3. Heater Dimensions and Clearances	13
3.1 Classic BX3C Model Guidelines	13
3.2 Service Clearances	14
3.3 Flue Terminal Clearances	14
3.4 Orientation of Flue Terminal	15
3.5 Area to Cut in the Wall.....	16
3.6 Installation of Flashing	16
3.7 Classic 2PWN Model Guidelines	17
3.8 Heater Dimensions 2PW26N & 2PW26N XA	18
3.9 Service Clearances	19
3.10 Splitting Classic 2PWN Heaters.....	19
4. Flueing	20
4.1 Internal Flueing Instructions.....	20
5. Fan Speed	21
5.1 Fan Speed Setting	21
6. Ducting And Outlets	22
7. Outlet Guide	23

8.	Thermostat Installation	24
8.1	Wiring the Manual or Programmable Thermostat (Heating Only)	24
8.2	Wiring the Bravis Programmable Thermostat (Add-On & Fan Only).....	26
9.	Commissioning and Control Settings	27
9.1	Commissioning Instructions	27
9.2	Start & Check Supply Pressure	27
9.3	Start & Check Burner Pressure.....	27
9.4	Setting the Fan Speed	28
9.5	Final Checks	28
10.	Bracket Positioning	29
10.1	Temperature limit positioning (applicable to BX315C/BX320C only)	29
11.	Technical Specifications	30
12.	Contacts	32

WARNINGS AND IMPORTANT INFORMATION



READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE.

Always comply with the following precautions to avoid dangerous situations and to ensure optimum performance.

Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.

DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in personal injury or death.

WARNINGS: Indicates a potentially hazardous situation which, if not avoided, could result in personal injury or death.

CAUTIONS: Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to the appliance. It may also be used to alert against unsafe practices.



REGULATORY / INSTALLATION

This appliance shall be installed in accordance with:

- Manufacturer's Installation Instructions.
- Current AS/NZS 5601, AS/NZS 5141 and AS/NZ 3000.
- AS 4254 - Ductwork for air-handling systems in buildings.
- HB 276-2004 – A Guide to Good Practice.
- Local Gas and Electricity Authorities.
- "SuperSizeGuide"
- Building Code of Australia (BCA) including local OH&S requirements
- Environment Authorities

This appliance must be installed, maintained and removed by an Authorised Person.

For continued safety of this appliance it must be installed and maintained in accordance with the manufacturers instructions.

This appliance is heavy, use 2 people or mechanical lifting device. Improper lifting may result in serious injury.

Take care when opening or unpacking this appliance. Failure to do so may result in serious injury or product failure.

DO NOT modify the electrical wiring of this appliance. If the control power wiring is damaged or deteriorated then it must be replaced by an authorised person. Failure to do so may result in electric shock, fire, serious injury or product failure.

DO NOT install the heater on an unstable or non level surface or where there may be a danger of it falling. It may result in death, serious injury, or product failure.

DO NOT install the outdoor unit where noise may cause nuisance.



A NOTE ON ILLUSTRATIONS

The illustrations used in this manual are for explanatory purposes only and the shape of your unit may vary slightly from that which is shown in this manual.



SAFETY WARNINGS

DO NOT place articles on or against this appliance

DO NOT use or store flammable materials near this appliance

DO NOT spray aerosols in the vicinity of this appliance while it is in operation

DO NOT modify this appliance



MANDATORY INSPECTION PRIOR TO INSTALLATION

Immediately report any damage or discrepancies to the Supplier of the appliance. This appliance was inspected and tested at the time of manufacture and packaging, and released for transportation without known damage. Upon receipt, inspect the exterior for evidence of rough handling in shipment. Ensure that the appliance is labelled correctly for the gas and electrical supply, and/or other services it is intended to be connected to.

For safety and warranty purposes, appliances that may be damaged or incorrect must not be installed or operated under any circumstances. Installation of damaged or incorrect appliances may contravene local government regulations. Rinnai disclaims any liability or responsibility whatsoever in relation to the installation or operation of damaged or incorrect appliances.



The manufacturer cannot guarantee compatibility and support for anyone using 3rd party accessory/devices (device) on any of their appliances.

The suitability, compatibility or functional performance of any 3rd party device is entirely the responsibility of the device's supplier or installer.

Any 3rd party device, technical, installation, operation, performance or other enquiries need to be referred to the device's supplier or installer.

Any adverse effects of 3rd party devices on the operation, performance or reliability of this appliance is not covered by the manufacturer's product warranty.

1. SCOPE

This installation manual is intended to be used as a guideline for the installation of Gas Fired Central Heaters. It covers only the installation and commissioning of the heater and the allowable flueing configurations. Although recommended return air grilles and allowable duct outlet quantities are specified, it does not cover the actual ducting design required to suit the installation.

This installation manual is based on Australian codes. For all other applications, please refer to local codes and regulations.

These heaters must be installed and serviced only by qualified personnel. This manual applies to the following models:

Brivis Classic Heaters

External Models	Internal Models
BX315C	2PW15N
BX320C	2PW20N
BX326C	2PW20N XA
	2PW26N
	2PW26N XA



The BX320C and BX326C models can be installed for extra air (XA) applications with an upgrade in base box size, and these are an optional accessory



Brivis Classic Ducted Gas Heaters do not have on-board Add-On Cooling connections, refer to the Add-On cooling section for more detail.

1.1 Installer Due Diligence for Changeovers

Modern ducted gas heaters, even those that are physically 'like-for-like', typically have different technical specifications and control systems to existing, older models. Modern units usually have higher Star Ratings, which are accompanied by higher airflows. Higher efficiency heaters with modulating gas valves also operate differently to non-modulating units.

When doing a direct unit change over:

- Do a comprehensive inspection of the entire existing system to ensure it is 'fit for purpose' with the new heater
- Check existing items that are not being replaced; i.e. ensure the soundness and suitability of all fittings and controls for use with the new ducted gas heater (e.g. Duct sizes, Flue, Return Air grille size, Thermostat, Zoning etc.)
- Correctly commission the new ducted gas heater – where possible, align it with the performance characteristics of the original system – do not leave units at the factory default settings unless you are absolutely certain the settings are appropriate

Failure to observe best practice can lead to costly call backs for installers, unnecessary manufacturer warranty calls and a poor customer experience.

With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.

Definitions

Shall

Indicates a mandatory requirement of this manual.

Should

Indicates a recommended requirement of this manual.

Any deviations from these instructions may, at the discretion of the manufacturer, void the warranty. As a result, the customer and/or installer may be charged a fee for non-product warranty related call outs. Also note that failure to comply with these instructions may preclude company service personnel from being able to service the unit.

Disclaimer



This document is a guide only. Laws, regulations and industry standards can vary between States and Territories. Accordingly, this guide must be read in conjunction with, and subject to, all laws, regulations and industry standards applicable in the State or Territory in which the products are installed. You must ensure that the installation of the products will comply with those laws, regulations and standards, and that the products recommended to customers are fit for the purpose for which they are intended.

2. GENERAL PRODUCT GUIDELINES

2.1 APPLICATION AND SIZING

These Classic heaters are designed to provide a central source of heat for a ducted central heating system.

The heaters should not be installed downstream from an air washer, an evaporative cooler or refrigerative cooling system. Nor are they designed to be installed on a marine craft, houseboat, or any similar environment.

The Classic heaters must be installed in accordance with these instructions and related regulations, codes, standards, and authorities. These include but may not be limited to:

- AS/NZS 3000 - Electrical Installations
- AS/NZS 5601 - Gas Installations
- AS 4254 - Ductwork for air-handling systems in buildings
- HB 276 - A Guide to Good Practice
- AS/NZS 5141 - Residential Climate Control Systems
- Local Gas and Electricity Authority Codes
- Brivis "SuperSizeGuide"/Brivisize™
- Product Sizing Guide
- Local Building Regulations
- Environment Authorities
- National Construction Code of Australia (NCC)

Brivis assumes no responsibility for equipment installed in violation of any code, regulations and these installation instructions.

It is recommended the Brivis "SuperSizeGuide"/Brivisize™ be followed in estimating heating requirements and for system design that will result in efficient installation and provide a higher level of comfort and economical operation. For the hourly input and the gas type to be used, see the appliance data label located inside the service compartment.



All installations should only be carried out by a qualified tradesperson. Installations at altitudes greater than 1000m above sea level may require upgrading of main burner injectors. Please contact the Customer Service Centre for advice.

It is recommended the Product Sizing Guide is followed in estimating heating requirements and for system design that will result in efficient installation and provide a higher level of comfort and economical operation.

For the hourly input and the gas type to be used, refer to the appliance data label located inside the service compartment or the Technical Specifications at the back of this manual.

2.2 INSPECTION

This appliance has been inspected and tested at the time of manufacture and packaging and released for transportation without known damage. Upon receipt, inspect the exterior for evidence of rough handling in shipment. Ensure that the appliance is labelled correctly for the gas to which it is intended to be connected. If a discrepancy or damage to the appliance is identified DO NOT install the appliance and report findings back to supplier.

2.3 UNPACKING THE HEATER

Some heaters are supplied on a pallet with a plastic sleeve. To unpack:

- Cut and remove the external plastic packaging and dispose of thoughtfully.
- Remove heater from pallet (if supplied).

Some heaters are supplied with a base box assembly wrapped with a removable plastic film to protect the surface.



ALWAYS remove and dispose of the plastic film before mounting the heater onto the base box.

2.4 UNLOADING OR LIFTING THE HEATER

When unloading or lifting the heater, ensure lifting equipment is in good operating condition and capable of lifting the total load. Be sure there is a clear area to place the heater down, which is within reach of the lifting equipment.



DO NOT use the lifting handles provided to lift the heater above head height. If fitting the heater to elevated heights such as a roof, use suitable lifting equipment.

2.5 SERVICE CONNECTION GUIDELINES

2.5.1 Gas Inlet Connection

- All piping must be in accordance with AS/NZS 5601 and any local gas regulations.
- The connection point for external model heaters is a female G3/4 compression fitting to AS 3688. This is either located on the outer cabinet of the heater, or supplied loose within the heater.

The connection point for internal model heaters is a male G3/4 compression fitting to AS 3688, located in the heater cabinet.

- A gas cock shall be fitted in the gas line adjacent to the heater and in a convenient location so it can be turned OFF quickly and easily.
- The gas supply shall in no way interfere with any servicing of the heater.



The gas supply **MUST** be installed by a licensed gas fitter. The gas pipe and gas meter should be sized so the heater can maintain its required incoming gas pressure at maximum consumption with all other gas appliances operating at their maximum capacity at the same time as the heater.

2.5.2 Electrical Power Supply

The heater is pre-wired with a 3-pin plug and lead, and shall be plugged into a standard 10 Amp 220-240V fixed switched socket outlet adjacent to the heater in a convenient location so it can be turned OFF quickly and easily.



A qualified electrician **MUST** install the 220 to 240 volt wiring according to local regulations.



Switch OFF the power and unplug the heater before touching any wiring. If any electrical wiring is damaged, it **MUST** be replaced by the manufacturer, its service agents or an electrically qualified technician, in order to avoid a hazard.

The electricity supply must be 220-240V at 50Hz, and supplied by an authorised power supplier. Generators should never be used to supply this system as their output may be incompatible with, or prone to damage electronic components of the heater.

2.6 INSTALLATION OF DUCT CONNECTION POPS

The supply and return air pops must be fastened to the heater cabinet as follows:

- Insert pop into the cabinet pop hole, ensuring the flange is placed over the wall of the cabinet
- Spread flange to tightly fit the cabinet pop hole with the notched side overlapping the other
- Secure pops with the rivets supplied

2.7 HEATER POSITIONING



All service clearance measurements **MUST** be adhered to, otherwise this will impede on the serviceability of the heater.

Install the heater in a position that allows adequate and safe access for service as per guidelines in this manual and its applicable standards. Otherwise, the cost of any equipment and additional labour involved in accessing such heater installations will not be accepted by Brivis.

2.8 INSTALLATION OF EXTERNAL HEATERS

The Classic BX3C range is designed to be installed outside of the house only. All heaters that are installed externally on the ground should be installed on a level concrete base or pad, and there must be provision made to drain away any surface water from the heater.

If the heater is to be installed in an elevated position, or on a roof, the installation must comply with AS/NZS 5601 Gas Installations. It must be secured to prevent movement, and it must have adequate provision for service access.

2.9 INSTALLATION OF INTERNAL HEATERS

The Classic 2PWN range is designed to be installed in the roof or beneath the floor.

This must be done in accordance with the following guidelines and AS/NZS 5601.

Installing in the Roof Space

- The area under the heater shall be capable of supporting the additional load, without causing deformation of any part of the building structure.
- The appliance shall be accessible by means of fixed access, a normal ladder or steps.
- A passage of 600mm wide shall be provided between the roof access opening and the heater.
- This passage shall have a suitable walkway of at least 19mm thick particle board or equivalent and be capable of supporting the weight of a person and their tools.
- A permanent level platform shall be provided beneath the heater and this platform area shall extend 750mm out from the controls access panel side and fan motor access panel side/s for the entire length of the heater.
- The air gap created between the base of the heater and the platform by the heater's supports must be maintained.
- Permanent artificial lighting must be provided at the heater, with the switch located at the roof access opening.

Installing Beneath the Floor

- There must be a minimum clearance of 200mm between any part of the appliance and the lowest part of the floor structure. In addition to this, refer to section "Service Clearances".
- The heater must be located within 2m of the access opening, or there is to be a minimum clearance of 1.2m between the lowest part of the floor structure and ground level, maintained from the access opening to the heater.
- All under floor installations must be on a level concrete base (50mm thick), and provision made to drain any seepage or ground water away from the heater.
- Permanent artificial lighting must be provided at the heater, with the switch located at the access opening.
- Lateral (horizontal) flues may be installed in accordance with AS/NZS 5601, making sure that the lateral flue section has a minimum rise of a 20mm per metre of lateral run.
- The flue must be terminated outside the building in accordance with AS/NZS 5601.

2.10 INSTALLATION OF INTERNAL HEATERS IN A ROOM, ENCLOSURE, RESIDENTIAL GARAGE OR PLANT ROOM

Installation of a gas appliance in a room or enclosure for properties approved for construction PRIOR TO March 31st 2014

- a. Determine if the rating per cubic metre of the space is greater than 3MJ/hr per m³.

Example:

Unit rating (Ur) = 120MJ/hr

Room volume (Rv) = 1m x 1m x 2.4m = 2.4m³

Ur/Rv = 120/2.4 = 50 MJ/hr per m³

As the result is greater than 3 MJ/hr per cubic metre of the space, additional ventilation is required.

- b. Two permanent openings are required, each equivalent in area to the determined value A. The lower vent shall be located close to the floor or at burner level. The upper vent shall be located at or above the top of the unit. The two openings may be combined as long as the above conditions are met.

Determine free ventilation area using $A = T \times F$, where:

A = minimum free ventilation area, mm²

T = total gas consumption of all gas appliances, MJ/hr. e.g. 1 x 2PW20N = 92MJ/hr

F = factor (detailed in the following table)

Table 1. Ventilation F Factors

Gas appliance location	Source of Ventilation	Factor F
Gas appliance in a room or enclosure	Directly to outside*	300
	Via an adjacent room	600
Gas appliance in a plant room	Directly to outside*	150
	Via an adjacent room	300
Gas appliance in a residential garage	Directly to outside*	300
* Directly to outside means through an external wall to outside, into a cavity vented to outside, into an underfloor space vented to outside, or into a roof space vented to outside.		

Installation of a gas appliance in a room or enclosure for properties approved for construction **AFTER March 31st 2014**

- a. Determine if the rating per cubic metre of the space is greater than 0.4 MJ/hr per m³.

Example:

Unit rating (Ur) = 120MJ/hr

Room volume (Rv) = 1m x 1m x 2.4m = 2.4m³

Ur/Rv = 120/2.4 = 50 MJ/hr per m³

As the result is greater than 0.4 MJ/hr per cubic metre of the space, additional ventilation is required.

Refer to AS/NZS 5601 for natural ventilation requirements.




For New Zealand ventilation requirements and all other applications, e.g. Mechanical Ventilation, refer AS/NZS 5601.

3. HEATER DIMENSIONS AND CLEARANCES

3.1 CLASSIC BX3C MODEL GUIDELINES

Install the heater in a position that allows adequate and safe access for service as per guidelines in this manual and applicable standards. The cost of any equipment and additional labour involved in accessing such heater installations will not be accepted by the manufacturer.

Diagram 1.



Dimension [mm]	BX315C	BX320C		BX326C	
A	985	985		1120	
B	852	852		1028	
C	616	616		706	
D	370	370		415	
E	772	772		952	
F	342	342		388	
G	36	36		42	
H	426	426		588	
I	162	162		244	
J	126	126		126	
K	392	392		558	
Base Box	Std	Std	XA	Std	XA
øSa	300	300	350	350	400
øRa	300	300	350	350	400

3.2 SERVICE CLEARANCES

Front

A minimum of 500mm must be provided at the side facing away from the house.

End

A minimum of 300mm must be provided at each end of the heater.

Top

A minimum of 1000mm must be provided above the heater roof. This clearance must be maintained for the entire surface area of the heater roof.

3.3 FLUE TERMINAL CLEARANCES

Heaters that are to be installed outside the house should be positioned so that when measured from the edges of the flue, the following minimum clearances exist, which are in accordance with AS 5601:

75mm

- From a drain or soil pipe.

150mm

- Out from the wall against which the unit is mounted.

300mm

- From any other flue terminal, cowl or combustion air intake.
- To a return wall or external corner.
- From the ground, above a balcony or other surface.
- Below eaves, balconies and other projections.
- Horizontally from an openable window, door, non-mechanical air inlet, or any other opening into a building (except sub-floor ventilation).

500mm

- From an electricity meter or fuse box (prohibited area extends to ground level).

1000mm

- Vertically below an openable window, non-mechanical air inlet or any other opening into a building (except sub floor ventilation).
- From a mechanical air inlet, including a spa blower, measured both vertically and horizontally.
- From a gas meter.

1500mm

- In the direction of discharge and horizontally from an openable window, door, non-mechanical air inlet, or any other opening into a building (except sub-floor ventilation)

For covered or recessed installations the following shall apply:


- When one side is open, the terminal shall be within 500mm of the opening, discharging in the direction of the opening and there shall be no opening into the building along the wall within that distance.

In both options for covered and recessed installations the terminal shall be located to ensure that a free flow of air across it is achieved.

3.4 ORIENTATION OF FLUE TERMINAL

The flue terminal for BX3C models is supplied and fitted to the heater as shown in Diagram 2. The flue terminal must be orientated correctly to ensure flue gases are expelled away from the building wall as shown.

Diagram 2.




Open area of flue terminal **MUST** be discharging away from building

3.5 AREA TO CUT IN THE WALL

When installing the heater at ground level, create one rectangular hole to suit the total pop width and height, all the way to ground level, refer Diagram 3.

Diagram 3.



Refer to the Base Box for required wall cut out dimensions.

3.6 INSTALLATION OF FLASHING

Flashing must be fitted to ensure the ductwork is adequately weather protected.

3.7 CLASSIC 2PWN MODEL GUIDELINES

Diagram 4.




Table 2.

Model	Dimension (mm)															
	A	B	C	D	E	F	G	H	I	J	K	L	M	øN	øRa	øSa
2PW15N	704	1147	412	723	115	160	385	491	200	269	747	791	1187	125	300	300
2PW20N	704	1147	412	723	115	160	385	491	200	269	747	791	1187	125	300	300
2PW20N XA	704	1147	412	723	115	160	385	491	200	269	747	791	1187	125	350	350

3.8 HEATER DIMENSIONS 2PW26N & 2PW26N XA

Diagram 5.





Table 3. 2PW26N & 2PW26N XA unit dimensions

Model	Dimension (mm)															
	A	B	C	D	E	F	G	H	I	J	K	L	M	øN	øRa	øSa
2PW26N	704	1226	538	722	113	160	445	572	263	269	813	791	1266	125	350	350
2PW26N XA	704	1226	538	722	113	160	445	572	263	269	813	791	1266	125	400	400

3.9 SERVICE CLEARANCES

Brivis internal heaters installed within the roof space shall be installed on a platform with minimum “Service Clearances” provided as detailed in Diagram 6. For more information regarding platform requirements refer to Section 1.9 “Installation of Internal Heaters”.

Diagram 6.



3.10 SPLITTING CLASSIC 2PWN HEATERS

The Classic 2PWN model heaters can be split in two to allow for ease of installation. To split the heater, follow these simple instructions:

- Remove the access panel located on top of the fan cabinet compartment by removing the two screws.
- Disconnect the fan motor loom active and neutral from the terminal block located inside the recess.
- Remove the fan motor loom earth terminal secured to the fan motor cabinet inside the recess.
- Remove the four screws, two screws on each side of the heater, fastening the fan cabinet to the heat exchanger cabinet.
- The heater can now be split in two.
- Protect the exposed looms from damage while the heater is split in two parts.
- Once in position, reassemble in reverse order.



NOTE Ensure when reassembling the heater that everything is put back and connected correctly.

4. FLUEING

4.1 INTERNAL FLUEING INSTRUCTIONS

Classic 2PWN models have both 100mm and 125mm flue connection options. There is a 100mm flue connection secured to the unit, with a removable 125mm adaptor already factory fitted. You may connect a 125mm flue directly to this adaptor, or if you elect to use a 100mm flue, simply remove the adaptor by sliding it off, and secure your flue to the 100mm connection.

General

- All flues must be installed in accordance with AS 5601 Gas installation Code.
- All horizontal flues must have a minimum rise of 20mm per 1m run.
- Horizontal flues terminating on a wall must be at least 300mm above ground level. For additional clearance requirements refer to section "3.3 Flue Terminal Clearances" on page 14.
- Provide adequate support to flue sections (e.g. saddles / strapping).

All Classic 2PWN models with a 125 mm flue:

- Require a **125 mm round single or twin wall non-corrosive metal flue**, and shall be terminated with an approved 125mm round metal flue cowl.
- All flues must have a bolted flue sleeve connection to allow for repairs and/or removal of the appliance.
- **Twin wall flue** – maximum flue length of **6m**.
- **Single wall flue** – maximum flue length of **2m**.
- Up to 4 x 90° elbows are permitted with the same length requirements specified above. One x 45° bend is equivalent to 0.5 x 90° bend (i.e. 2 x 45° bends = 1 x 90° bend).

All Classic 2PWN models with a 100 mm flue:

- Require a **100 mm round single or twin wall non-corrosive metal flue**, and shall be terminated with an approved 100mm round metal flue cowl. The Brivis Remote Flue terminal (part number B018384) may be used to terminate the flue on the outside wall of the building, typically under floor installations.
- All flues must have a bolted flue sleeve connection to allow for repairs and/or removal of the appliance.
- **Twin wall flue** – maximum flue length of **6m**.
- **Single wall flue** – maximum flue length of **2m**.
- Up to 2 x 90° elbows are permitted with the same length requirements specified above. One x 45° bend is equivalent to 0.5 x 90° bend (i.e. 2 x 45° bends = 1 x 90° bend).

5. FAN SPEED


5.1 FAN SPEED SETTING

There are three fixed fan speed options available with the Classic units, these are:

- High – “HIGH” (Factory Default)
- Medium – “MED”
- Low – “LOW”

The fan speed setting can be modified at the “4-Way Terminal Block” and for its location refer to Diagram 7.

Diagram 7. 4-Way Terminal Block Location



To adjust the fan speed setting ensure the power supply to the unit is OFF at the fixed switched socket outlet adjacent to the heater. Access controls and change as required:

- For High fan speed do not adjust.
- For Medium fan speed move terminal from “**HIGH**” to “**MED**”.
- For Low fan speed move terminal from “**HIGH**” to “**LOW**”.
- Turn the power back on once complete.

6. DUCTING AND OUTLETS

6.1 DUCT DESIGN AND SIZING

Good duct design and sizing are essential to every Central Heating system. Use the Brivis "SuperSizeGuide"/ Brivisize™ and technical data within this manual for the best results and follow these guidelines:

- Ductwork should be well insulated, airtight and have a minimum insulation rating of R1.0 (R1.5 in some areas). Ensure that ducting complies with the Building Code of Australia
- The ducting should be well fastened to pops, BTO's, outlet boots and neck adapters adequately with duct tape, in accordance with AS 4254, HB 276 and AS5141.
- It should be correctly sized with the curves and bends smooth enough to ensure the air flows through efficiently and quietly with minimal resistance
- The registers and diffusers should be large enough and of good design. They should minimise noise, while providing the correct distribution pattern
- The positive return air system should be fitted with a grille large enough to accept the full air capacity of the system at low noise levels and minimum resistance
- If the system uses high level outlets (e.g. ceiling diffusers), then the return air inlet should be at a low level. Ceiling systems with a high level return air may result in reduced performance



It is important that the ducting should be well insulated. It is mandatory under building codes to install insulated, fire rated duct.

6.2 RETURN AIR GRILLE

If a filter is fitted to the return air grille, make sure it is easily accessible for regular cleaning.

Table 4 gives the minimum recommended return air grille sizes for each model heater.

Table 4. Minimum Recommended Return Air Grille Selection

Model	Without Filter		With Filter	
	Grille Size (m ²)	Example Size (mm)	Grille Size (m ²)	Example Size (mm)
BX3C Models				
BX315C (300mm)**	0.19	(400x500)	0.28	(400x700)
BX320C (300mm)**	0.22	(400x550)	0.32	(400x800)
BX320C (350mm)**	0.24	(400x600)	0.35	(400x850)
BX326C (350mm)**	0.32	(400x800)	0.46	(400x1150)
BX326C (400mm)**	0.35	(400x900)	0.51	(400x1300)
2PWN Models				
2PW15N	0.17	(400x450)	0.25	(400x625)
2PW20N	0.20	(400x500)	0.29	(400x725)
2PW20N XA	0.22	(400x550)	0.31	(400x775)
2PW26N	0.33	(400x825)	0.48	(400x1200)
2PW26N XA	0.36	(400x900)	0.52	(400x1300)

****Model and (Base Box Pop) size**

For example a grille with a free ventilation opening measuring 400mm x 600mm, the grille size is 0.40m x 0.60m = 0.24m². This grille would be suitable for a BX320C XA (350mm pops) heater provided the grille does not have a filter fitted.



Grille sizes in Table 4 are for Egg-Crate Grilles and are based on airflows at a static pressure of 125 Pa for 26 kW models and 50 Pa for 15 kW and 20 kW models. For all other grille types, consult grille manufacturer's specifications.

7. OUTLET GUIDE

The outlet table provides recommendations based on using the Brivis "SuperSizeGuide" / Brivisize™ or a system designed using accepted design principles. These figures also relate to typical size registers and diffusers used on domestic heating systems i.e. 300mm x 100mm floor registers and 150mm round ceiling diffusers, with 150mm ductwork connection. For all systems, a minimum number of outlets must remain fully open (this includes both the outlet grille and the damper in the duct) if the heater is to operate properly without overheating. Similarly, ceiling outlet systems have a maximum number of outlets that can remain fully open, to ensure that the velocity through each outlet is sufficient. These maximum ceiling outlet figures relate to fully open outlets. However, the system will operate efficiently with more outlets open, if it has been properly balanced.

The outlet table has been divided into two columns as follows:

Table 5. Outlet table

Model	Airflow Rate (l/s)	A Maximum Outlets	B Minimum Outlets
BX3C Models			
BX315C (300mm)**	498	8	4
BX320C (300mm)**	581	11	5
BX320C (350mm)**	622	11	5
BX326C (350mm)**	819	16	8
BX326C (400mm)**	921	16	8
2PWN Models			
2PW15N	452	10	5
2PW20N	527	13	7
2PW20N XA	561	13	7
2PW26N	858	17	8
2PW26N XA	944	17	8

A. The maximum number of outlets that should remain fully open for a ceiling outlet system.

B. The minimum number of outlets that should remain fully open for floor/ceiling systems.

**Model and (Base Box Pop) size*



Airflow figures are based on a total static pressure of 125Pa for the 26 kW model, and 50Pa for the 15kW and 20kW models.



The maximum and minimum number of outlets detailed in Table 5 are as per AGA specification.

8. THERMOSTAT INSTALLATION

All Brivis heating systems can be controlled by various Brivis Thermostats, each explained in detail below. A Thermostat inside the house is wired to the control module in the heater. The Thermostat monitors the temperature in the house and switches the system ON and OFF in order to maintain a set temperature. Therefore, it must be positioned correctly.

- **Install in the living area:** It is important that the Thermostat is placed in a position that will provide the most accurate reading of the temperature, i.e. in the area most often used for family living.
- **Attach on an internal wall:** The temperature difference on an external wall can also affect it, so always mount it on an internal wall. Keep hole in the wall for the wiring as small as possible to prevent draught from within the wall cavity affecting the temperature setting.
- **Get the height right:** The Thermostat should be approximately 1500mm above the floor level.
- **Avoid hot spots:** Keep it as far away as possible from warm air outlets, radiation from the sun, fireplaces, radio and television sets, or warm pipes and duct running in the wall behind it.
- **Avoid cold spots:** Keep it as far away as possible from draughts caused by doorways, stairwells, windows or return air inlets.
- **Avoid dead spots:** Keep it away from areas of less than normal air circulation, e.g. behind doors, in alcoves or corners.
- **Interference from other electrical connections:** Ensure the Thermostat and wiring is kept away from other electrical, data and antenna cables. This includes keeping the Thermostat's wiring away from the spark igniter loom within the heater's cabinet.
- **Use the right cables:** Ensure the cable is 0.75mm² in cross section and less than 100m in length.



DO NOT install the control wiring with the power turned on, as the fuse may blow, which would not be covered under warranty.

8.1 WIRING THE MANUAL OR PROGRAMMABLE THERMOSTAT (HEATING ONLY)

Brivis Manual and Brivis Programmable Thermostats can be wired directly to a Classic heater for heating only applications.



Only use Brivis Thermostats, as any failure relating to a non-Brivis Thermostat will not be covered under warranty.

To connect the Thermostat to the unit:

- Run twin core cable no less than 0.75mm² in cross section from the heater “**W & R Terminal Block**” to the thermostat location.
- Remove thermostat backing plate from the front cover and mount on the wall.
- Draw wires from the wall cavity, connect W & R terminals on the heater “**W & R Terminal Block**” to the W & R terminals on the thermostat, refer to Diagram 8 and Diagram 9.
- Insert batteries and mount thermostat front cover onto the backing plate.
- For more information refer to the Installation Guide and Operating Manual supplied with the Brivis Manual or Programmable Thermostats.

Diagram 8. BX3C Thermostat Connection





Diagram 9. 2PWN Thermostat Connection



8.2 WIRING THE BRIVIS PROGRAMMABLE THERMOSTAT (ADD-ON & FAN ONLY)


The Classic control board does not have provision for “Add-On” cooling or “Fan Only” operation. For “Add-On” cooling or “Fan Only” operation the unit must be configured.

To facilitate Add-On Cooling or Fan Only operation an additional accessory, ‘ACC LOOM ADD-ON RELAY CLASSIC’ (Brivis Part No. B063283) must be fitted.

To configure a BX3C or 2PWN unit for “Add-On” cooling refer to Diagram 10.

To configure a BX3C or 2PWN unit for “Fan Only” operation refer to Diagram 10 and omit the “Y” connection. For more information regarding connection of the Add-On relay refer to the installation instructions supplied with ‘ACC LOOM ADD-ON RELAY CLASSIC’ (Brivis Part No. B063283).

Diagram 10. BX3C & 2PWN Brivis Ice Add-On Schematic - Typical



For Brivis ICE Add-On connection to a Brivis Classic heater (CC3, 2PWN, or BX3C) an additional relay ‘ACC LOOM ADD-ON RELAY CLASSIC’ (Brivis Part No. B063283) must be fitted.

Contact Technical Support for information on superseded Brivis Heaters.



**All electrical works to comply with relevant regulations.
Requires Brivis programmable Thermostat.**

9. COMMISSIONING AND CONTROL SETTINGS

All Brivis heaters have been factory tested. However, they should be commissioned and adjusted in accordance with the following instructions to ensure efficient and optimal heating performance.

Remember:

- Switch the mains power OFF before touching any wiring
- All these steps must be carried out by a qualified tradesperson
- If the heater cannot be adjusted to operate in accordance with these instructions, then contact the Customer Service Centre (contact details are on the back cover of this manual)

9.1 COMMISSIONING INSTRUCTIONS

With a correctly designed and installed ducted system, generally the balancing damper in an outlet register should be initially set as follows:

- Living areas: 100% open
- Bedrooms: 50% open
- Bathrooms, ensuite & Laundry: 25% open

9.2 START & CHECK SUPPLY PRESSURE

1. Turn OFF the 240 Volt ac power supply at the fixed switched socket outlet adjacent to the unit.
2. Ensure the gas cock adjacent to the heater is in the OFF position.
3. Locate gas valve inlet pressure test point, remove the grub screw and insert your test point fitting (hose tail 1/8" NPT).
4. Attach a manometer to the test point.
5. Ensure that all air has been purged from the gas piping and then turn ON the gas cock adjacent to the unit.
6. Turn on the 240 Volt ac power supply adjacent to the unit.
7. Go to the Thermostat, turn it ON and increase the temperature setting so that it calls for heat.
8. The unit will now attempt to ignite.
9. Once the ignition is successful allow the unit to run for one minute, ensuring the gas supply pressure does not fall to below 1.1kPa while other gas appliances are operating at their full capacity.
10. If the reading is below 1.1kPa, then the incoming gas supply is inadequate (check supply pipe for blockage, and check pipe sizing and gas meter sizing).
11. Turn the unit OFF at the thermostat, isolate the gas and the 240 Volt power supply adjacent to the unit.
12. Remove and replace test point with the grub screw.



If the unit does not ignite on the first attempt it may be a result of all air not being purged from the gas supply line. The heater will attempt to ignite up to five times before locking out, after which it will require a power reset.

If the heater does not attempt ignition at all:

- Check the Lighting Procedure again and if it still fails to light, by-pass the Thermostat by removing cables from the terminal block at the unit and link (bridge) terminals "R" and "W". If it then lights, there is a fault with the wires to the Thermostat or in the Thermostat itself. If it does not light, check the overheat switch has not tripped or the 2 amp fuse has not blown.

9.3 START & CHECK BURNER PRESSURE

1. Repeat steps 1 to 7 in Section 9.2. For step 3 locate the burner pressure test point fitted on the gas valve or the burner manifold.
2. Take a manometer reading of the test point pressure and confirm it is equal to the figure shown on the appliance data label. If the pressure reading is not correct, adjust the gas valve pressure regulator either up or down to match the required test point pressure. If the pressure is lower than the required amount and cannot be adjusted any higher, this indicates that the incoming supply pressure is not sufficient (check supply pipe for blockage, and check pipe and gas meter sizing).

9.4 SETTING THE FAN SPEED

Classic Heaters are fitted with a single speed room fan with High, Medium and Low fan speed options. Refer to "5. Fan Speed" on page 21 to change the desired fan speed. Set the fan speed to achieve, as close as possible, a temperature rise at the nearest outlet to the heater above the inlet (Return Air) temperature for the type of system as follows:

- **Floor Outlet System:** 35° to 40° C rise (e.g. Return Air temp at 20° C plus 35° C rise equals a 55° C outlet temperature).
- **Ceiling or High Level outlet System:** 25° to 30° C rise. If the outlet air is hotter than recommended then a higher fan speed should be selected to reduce the outlet temperature. If it is lower, then reduce the fan speed.



The temperature of the warm air at any outlet should not be more than 45° C above the return air temperature.

9.5 FINAL CHECKS

Confirm:

1. Minimum flowing gas pressure is 1.1 kPa (NG units) with all other gas appliances in operation.
2. The burner pressure is as indicated on the appliance data label.
3. The temperature of the warm air at any outlet is not more than 45° C above the return air temperature.
4. The fan continues to run while the burners are operating.

Once Confirmed:

- Turn the heater OFF at the thermostat.
- Ensure that the burners and fan turn OFF, then turn OFF the gas supply at the supply tap and remove the manometer hose and fitting from the pressure test point.
- Replace and tighten the test point screw, turn ON the gas supply at the supply tap, start up the heater again and test for leaks using a soapy water solution or a leak detector spray.
- Replace controls access panel, then proceed to instruct the customer on correct operation of the system and assist the customer to fill in the Warranty Card details.
- Issue any required documentation to the relevant people/authorities in regards to the installation of the heater, the gas connection and power supply (for example, a Certificate of Compliance and Certificate of Electrical Safety).



Product warranty registration forms for Australia can be found online at brivis.com.au


10. BRACKET POSITIONING

10.1 TEMPERATURE LIMIT POSITIONING (APPLICABLE TO BX315C/BX320C ONLY)

The temperature limit sensor bracket is tucked within the cabinet cavity for transportation purposes.

- Please ensure the bracket is positioned as illustrated in Diagram 11 during installation/commissioning.
- Make sure that the overheat bracket is not bent past the angle stopper.

Diagram 11. Temperature limit sensor bracket position



Failure to comply may result in abnormal heater operations.

11. TECHNICAL SPECIFICATIONS

Table 6. Classic Heaters Technical Specifications

Models	Gas Input MJ/hr	Heat Output kW	Duct Connection Pop Sizes (mm)	Minimum Recommended Return Opening		Airflow @ Total Static Pressure (L/s)				Weight (kg)	Fan Motor		Total Maximum Current (A)	Maximum Recommended Add-On Cooling Capacity (kW)
	Max Input NG	Max Output NG		No Filter (m²)	With Filter (m²)	50 Pa	75 Pa	100 Pa	125 Pa		Power (W)	Current (A)		
BX3C Models														
BX315C (300mm)**	66	15.5	300	0.19	0.28	498	480	461	443	48	425	2.5	4	n/a
BX320C (300mm)**	87	20	300	0.22	0.32	581	561	541	521	49	425	2.5	4	n/a
BX320C (350mm)**	87	20	350	0.24	0.35	622	598	574	553	49	425	2.5	4	10
BX326C (350mm)**	120	28	350	0.32	0.46	896	873	849	819	72	600	6	6.5	13
BX326C (400mm)**	120	28	400	0.35	0.51	1012	985	957	921	72	600	6	6.5	15
2PWN Models														
2PW15N	67	15.5	300	0.17	0.25	452	430	412	386	51.5	250	1.8	4	n/a
2PW20N	92	21	300	0.20	0.29	527	511	487	460	54.6	315	2.5	4	n/a
2PW20N XA	92	21	350	0.22	0.31	561	544	519	490	54.6	315	2.5	4	10
2PW26N	121	28	350	0.33	0.48	941	913	885	858	66.5	600	4.4	6	17
2PW26N XA	121	28	400	0.36	0.52	1035	1004	974	944	66.5	600	4.4	6	18

**Model and (Base Box Pop) size



The temperature of the warm air at any outlet should not be more than 45° C above the return air temperature.

NOTES

Rinnai Australia Pty Ltd

ABN 74 005 138 769 | AU45204

100 Atlantic Drive, Keysborough, Victoria 3173
P.O. Box 460, Braeside, Victoria 3195
Tel: (03) 9271 6625
Fax: (03) 9271 6622

National Help Line

Tel: 1300 555 545* Fax: 1300 555 655
Monday to Friday, 8.00 am to 5.00 pm EST.

**Cost of a local call higher from mobile or public phones.*

For further information visit **www.rinnai.com.au**
or email **enquiry@rinnai.com.au**

Rinnai has a Service and Spare Parts network with personnel who are fully trained and equipped to give the best service on your Rinnai appliance. If your appliance requires service, please call our National Help Line. Rinnai recommends that this appliance be serviced every 2 years.

With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.