



**NOT SUITABLE FOR WALL TO WALL

*PLEASE NOTE: FOR SEMI INSET VANITIES & CENTRE VOID

- DRAWER SIDES START 135MM FROM TOP OF CORIAN
- 120MM DRAWER BOX SIDES
- SEMI INSET & CENTRE VOID REQUIRES A CUTOUT IN DIVISION: 135MM FROM TOP OF CORIAN, 415MM WIDE