

# KADO

## Kado Lux Semi Inset Basin 1 Taphole with Overflow White

9507797

### INSTALLATION INSTRUCTIONS

1. Position basin onto bench top and mark off for semi inset installation.
2. Cut hole in bench top to suit waste and tapware.
3. Fit selected waste to basin. Ensure waste is sealed top and bottom.
4. Apply waterproof sealant (not supplied) to the rim of the basin and to the bench top.
5. Fit basin onto the bench top and press firmly all around to achieve good seal.
6. Remove surplus sealant.

**Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference.**