

Mizu Bloc MK2 Waterfall Bath Outlet

IMPORTANT NOTE:

Outlet must be installed to the requirements of AS/NZS 3500 by a qualified plumber.

INSTALLATION INSTRUCTIONS:

1. Please flush out new pipe work prior to connecting the new outlet
2. Screw adaptor (1) onto 15mm bsp thread (1/2 inch) using a 12mm allen key. Use PTFE tape to seal the thread
3. The back of the adaptor needs to finish flush against the finished wall
4. Push the outlet onto the adaptor, ensuring it is level
5. Secure into position by tightening the grub screw using 2.5mm allen key

CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions