

# **Kado Era Pillar Taps (5 Star)**

# IMPORTANT INFORMATION, please read before starting installation.

- 1. This tapware may come partially assembled. This is for packaging purposes only.
- 2. It is the plumbers responsibility to ensure that all assembled components and threaded joins are checked for correct assembly prior to installing.
- 3. All threaded joins are to be taped with suitable plumbers tape or sealed with a recommended sealing compound.
- 4. Prior to installation, the tapware must be pressure tested using the appropriate testing equipment.
- 5. Prior to installation, the installer is responsible for ensuring installation of the correct plumbing fittings and the set out distances are correct for the product supplied.

# FOR THE PLUMBER:

- 1. All work should be carried out by a licensed plumber. Responsibility will not be accepted for incorrect installation of this tapware, or any tapware not installed by a Registered Plumber.
- 2. The water supply lines need to be 'flushed out' prior to installation. This will avoid any foreign materials blocking the flow regulator, damaging the cartridge/valve and reducing the flow of water.

#### For Basin/Sink Installation:

- 3. Insert the spout assembly into the center hole of basin or sink and securely mount from the underside of the basin or sink.
- 4. Remove the handle and flange from the tap bodies. Trim the breaching piece if necessary to suit with the basin or sink hole centres. Assemble with the tap bodies.
- 5. Insert the tap bodies through the underside of basin or sink. Complete the assembly by installing back the flange cover and handle.
- 6. Connect the correct water supplies to the tap bodies.
- 7. Ensure all connections are tight.
- 8. Turn on the main water supply and check for leaks.

# For Wall Installation:

- 3. Connect the spout assembly into the wall outlet.
- 4. Install the stuffing box assembly to the wall connection. Ensure it is connected to the correct water supply.
- 5. Ensure all connections are tight.
- 6. Turn on the main water supply and check for leaks.

# For Hob Installation

- 3. Connect the spout assembly into the hob outlet.
- 4. Install the stuffing box assembly to the hob connection. Ensure it is connected to the correct water supply.
- 5. Ensure all connections are tight.
- 6. Turn on the main water supply and check for leaks.

# For Singe Inlet Installation:

- 3. Connect the tap assembly into the outlet.
- 4. Ensure all connections are tight.
- Turn on the main water supply and check for leaks.

