

Mizu Drift Mk2 Shower Mixer

IMPORTANT NOTE:

Mixer must be installed to the requirements of AS/NZS 3500 by a qualified plumber. Your mixer comes to you already factory assembled and tested. We do not recommend the dismantling of any internal part of the mixer. The mixers are factory tested and sealed so as to give the best performance.

INSTALLATION INSTRUCTIONS:

1. Flush out new pipe work prior to connecting the new mixer
2. During installation, protect the cartridge sleeve (8) surface by using the plastic cover (15) provided. Pay attention to shower mixer and cover plate dimensions when working out installation depth. If required, manipulate the mounting surface to allow for a suitable installation depth.
3. Shower mixer is ideally suited for timber/metal noggin installation using fastening screws for mounting. If an alternative installation method is intended (e.g. block wall) take appropriate steps to ensure a suitable installation.
4. The shower mixer outlet must always face up towards the shower and be aligned straight
5. Connect the hot water supply line to the hot 'H' inlet and the cold water supply line to the cold 'C' inlet in the mixer
6. Connect the shower outlet line to the outlet connection in the shower mixer
7. Pressure check all connections as to AS/NZS 3500
8. After the finished wall is completed, remove the plastic cover, and fit the wall cover plate (10)
9. Use an appropriate sealing compound to seal the cover plate edges to the wall
10. Fit the handle (1)(4) by fitting the handle slot over the mixer cartridge (7) lever. Use the supplied Allen key (16) to tighten the grub screw (3) in the handle till it is firmly secured. Insert the grub screw hole cover (2) into the handle.

CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions