

KADO

Kado Era Wall Sink Set (5 Star)

INSTALLATION INSTRUCTIONS

IMPORTANT INFORMATION, please read before starting installation.

1. This tapware may come partially assembled. This is for packaging purposes only.
2. It is the plumbers responsibility to ensure that all assembled components and threaded joins are checked for correct assembly prior to installing.
3. All threaded joins are to be taped with suitable plumbers tape or sealed with a recommended sealing compound.
4. Prior to installation, the tapware must be pressure tested using the appropriate testing equipment.
5. Prior to installation, the installer is responsible for ensuring installation of the correct plumbing fittings and the set out distances are correct for the product supplied.

FOR THE PLUMBER:

1. All work should be carried out by a licensed plumber. Responsibility will not be accepted for incorrect installation of this tapware, or any tapware not installed by a Registered Plumber.
2. The water supply lines need to be 'flushed out' prior to installation. This will avoid any foreign materials blocking the flow regulator, damaging the cartridge/valve and reducing the flow of water.

For Basin/Sink Installation:

3. Insert the spout assembly into the center hole of basin or sink and securely mount from the underside of the basin or sink.
4. Remove the handle and flange from the tap bodies. Trim the breaching piece if necessary to suit with the basin or sink hole centres. Assemble with the tap bodies.
5. Insert the tap bodies through the underside of basin or sink. Complete the assembly by installing back the flange cover and handle.
6. Connect the correct water supplies to the tap bodies.
7. Ensure all connections are tight.
8. Turn on the main water supply and check for leaks.

For Wall Installation:

3. Connect the spout assembly into the wall outlet.
4. Install the stuffing box assembly to the wall connection. Ensure it is connected to the correct water supply.
5. Ensure all connections are tight.
6. Turn on the main water supply and check for leaks.

For Hob Installation:

3. Connect the spout assembly into the hob outlet.
4. Install the stuffing box assembly to the hob connection. Ensure it is connected to the correct water supply.
5. Ensure all connections are tight.
6. Turn on the main water supply and check for leaks.

For Singe Inlet Installation:

3. Connect the tap assembly into the outlet.
4. Ensure all connections are tight.
5. Turn on the main water supply and check for leaks.