



## PLUMBERS INSTALLATION INSTRUCTIONS

### For Vitreous China Leda Urinal

#### PLEASE READ CAREFULLY BEFORE INSTALLATION

##### ROUGHING IN FOR THE BRACKET AND TRAP POSITIONS

For timber stud walls the noggings and studs must be positioned at a height to allow for the location of the fasteners. The centre position is detailed in **Fig 1**.

##### ROUGHING IN FOR THE SPARGE PIPE AND WASTE/DRAIN PIPE

Accuracy is required between the two pipes as detailed in **Fig. 1 & 2**.

##### ROUGHING IN FOR THE PEDESTAL

Accurate waste/drain pipe set-out is essential for the pedestal installation as detailed in **Fig. 3**.

##### 'P' TRAP URINAL INSTALLATION

- Once the roughing in details have been confirmed on the wall as detailed in **Fig. 1 & 2**.
- Fit the outlet kee seal over the waste/drain pipe spigot protruding from the wall.
- Gently push the urinal 'P' trap onto the kee seal using a soap solution lubricant.
- Centre the trap in the vertical position and mark the three screw holes.  
**(Note:** the top screw hole is offset to the left of centre line by 10mm (3/8") as detailed in **Fig. 1**.
- Secure the trap onto the wall using suitable fasteners.  
**(Note:** fix pedestal as **Fig. 5 & 6** 'S' trap installation if required.
- Fix the Leda Urinal Fixing Bracket into position as detailed **Fig. 1**.
- Fit the inlet kee seal on to the sparge pipe and position the urinal over the pedestal if required ensuring that the sparge pipe is aligned with the kee seal. (Use soap solution lubricant on the seals)
- Push the urinal gently onto the sparge pipe while engaging the outlet into the trap seal.
- Secure the urinal onto the concealed bracket using plastic fixing sleeve into holes in the urinal, screw the two threaded studs into the bracket, as detailed in **Fig. 5**. Tighten fixing heads with a 1/4" Allen key (not supplied) to mount urinal to wall while ensuring level.

**IMPORTANT-DO NOT OVER TIGHTEN, AS THIS MAY CRACK THE URINAL SIDE.**  
Snap on plastic cap, as detailed in **Fig. 5**.

- Caulk with an acetic cured silicone sealant/caulking as required.

##### 'S' TRAP URINAL INSTALLATION

- Once the roughing in details have been confirmed on the wall as detailed in **Fig. 1 & 3**.
- Position the plastic 'S' trap loosely over the waste/drain pipe.
- Centre the trap in the vertical position against the wall and mark the three screw holes.  
**(Note:** the top screw hole is offset to the left of centre line by 10mm (3/8") as detailed in **Fig. 1**.
- Tighten the outlet nut onto the waste/drain pipe to make a watertight seal and secure the trap onto the wall using suitable fasteners.
- Place the pedestal in position on the centre line and mark the screw hole positions.
- Secure the pedestal in position using appropriate fasteners.
- Fix the Leda Urinal Fixing Bracket in position as detailed in **Fig. 1**.
- Fit inlet kee seal onto to the sparge pipe and position the urinal over the pedestal ensuring that the sparge pipe is aligned with the kee seal. (Use soap solution lubricant on the seals)
- Push the urinal gently onto the sparge pipe while engaging the outlet into the trap seal.
- Secure the urinal onto the concealed bracket using plastic fixing sleeve into holes in the urinal, screw the two threaded studs into the bracket, as detailed in **Fig. 5**. Tighten fixing heads with a 1/4" Allen key (not supplied) to mount urinal to wall while ensuring level.
- Caulk with an acetic cured silicone sealant/caulking as required.