

Blossom II Vanity Unit

Vanity should be installed by a qualified, licensed trade person.

Vanity Fitting Instructions

- Prior to installation it is important to inspect the vanity to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with the installation and advise supplier immediately. No warranty claim for damage will be accepted if the vanity is installed.
- Prior to installation check wall/tile surface where unit will be fitted is flat and even. Installing on uneven wall will result in the unit twisting – DO NOT PROCEED.
- It is recommended that the Solid Surface Top is protected during installation.

PLEASE NOTE: MANUFACTURER WILL NOT BE LIABLE FOR THE COST OF INSTALLATION OR REMOVAL OF THE VANITY & THE WARRANTY WILL BE VOIDED IF DAMAGE OCCURRED DURING INSTALLATION.

1. To aid Installation; first remove doors by unscrewing the hinges. Doors will slide off hinge bracket. Place doors in a secure location in the meantime.

2. Check that the unit will fit into the location. On timber studded walls, mark the positions of the studs, so to be able to fix the unit to these later.

3. Line up the unit so that the units waste chamber aligns with the corresponding plumbing. Holes for waste outlet through the back are not pre-drilled. This outlet is left to the discretion of the plumber. Mark where unit is to be installed.

4. Mount unit by screwing through any part of the back of the unit into the wall, ensuring contact to studs.

5. Ensure Corian is right way up. Silicon to secure and mount permanently. Additional Silicon is also required on the edge of the vanity where the Corian meets the tiles/wall. If wall to wall, all four edges require Silicon.

6. Attach doors back on by sliding the hinges back on the bracket, and screw accordingly.

7. Ensure the vanity is installed level; as this will effect the alignment of the doors.

**Recommendation for Plumbing

Waste should not be over tightened to avoid stress on basin and top.

REMOVE DRAW



1. Fully extend drawer
2. Squeeze Clips and carefully pull drawers out.

HEIGHT ADJUSTMENT AT BACK



1. Roll wheels left to right to move draw up and down

