

Milli Monument Edit Robe Hook, Towel Ring & Toilet Roll Holder

ROBE HOOK

TOWEL RING

TOILET ROLL HOLDER

1. Release the mounting bracket from the flange by loosening the grub screw located underneath.
2. Place the mounting bracket against the fixing surface, flat side down, at the desired vertical and horizontal position. Mark the required fixing position through the holes in the mounting bracket (see Illustration 2).
3. Drill holes (using the appropriate drill size and type) into the fixing surface as accurately as possible, taking care to drill at the centre of each marking.
4. Fix the mounting bracket to the fixing surface, flat side down (see Illustration 4). Adjust until the mounting bracket is level before tightening the screws (use the appropriate wall anchor if required).
5. Place the flange onto the mounting bracket ensuring a flush fit. Tighten the grub screw to ensure a secure mount (see illustration 5).

