KADO Kado Era Wall Basin Outlet (5 Star)

INSTALLATION INSTRUCTIONS

IMPORTANT INFORMATION, please read before starting installation.

- 1. This tapware may come partially assembled. This is for packaging purposes only.
- 2. It is the plumbers responsibility to ensure that all assembled components and threaded joins are checked for correct assembly prior to installing.
- 3. All threaded joins are to be taped with suitable plumbers tape or sealed with a recommended sealing compound.
- 4. Prior to installation, the tapware must be pressure tested using the appropriate testing equipment.
- 5. Prior to installation, the installer is responsible for ensuring installation of the correct plumbing fittings and the set out distances are correct for the product supplied.

FOR THE PLUMBER:

- 1. All work should be carried out by a licensed plumber. Responsibility will not be accepted for incorrect installation of this tapware, or any tapware not installed by a Registered Plumber.
- 2. The water supply lines need to be 'flushed out' prior to installation. This will avoid any foreign materials blocking the flow regulator, damaging the cartridge/valve and reducing the flow of water.
- Install the stuffing box assembly to the wall connection. Ensure it is connected to the correct water supply.
- 4. Ensure all connections are tight.
- 5. Turn on the main water supply and check for leaks.

