



Posh Domaine Polished Edge Mirror

MIRROR INSTALLATION

- Prior to installation it is important to inspect the Polished Edge mirror to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, DO NOT proceed with installation and advise place of purchase immediately. No warranty claim for damage will be accepted if the mirror is installed. This includes scratches to the glass.
- It is recommended that the mirror is protected during installation. Please Note: Manufacturer will not be liable for the cost of installation or removal of the mirror and the warranty will be voided if damage occurred during or after installation.
- Mark the wall where the mirror is going to be placed.
- Turn mirror over and measure the center locations of each bracket.
- With these measurements, using your marked wall as a guide, mark center location for each bracket for your drill holes. Check these markings with a spirit level to ensure it is level. IT IS RECOMMENDED THAT SCREWS ARE FIXED TO STUDS TO ENSURE STRENGTH OF FIXING.
- Drill into wall with a drill bit appropriate to your finished wall. When mounting to a hollow wall, use plugs provided. Gently hammer plastic plugs into holes and screw the supplied screws into the plastic plugs leaving approximately 10mm proud of the wall.
- Hook mirror to the wall.

MIRROR SHOULD BE INSTALLED BY A QUALIFIED, LICENSED TRADES PERSON.



CARE & MAINTENANCE

If you cannot identify basin, top or cabinet material of your product, contact your merchant or see product information at www.adpastralia.com.au.

TIPS

- ADP products are produced from materials that are well suited to the bathroom, however it is important that your bathroom has sufficient ventilation to avoid excessive moisture. High humidity will lead to permanent dampness and mould, resulting in deterioration of the materials.
- Care must always be taken to dry any excessive moisture or water spillage.

MIRRORS

FOR BEST RESULTS - use a slightly moistened microfibre cloth to remove dry dirt or grime, then buff clean with dry microfibre cloth or use a soft dry cloth with a tight weave (which is more soft and non-abrasive). This will leave you with a clean, smear-free finish. By using alkaline (ammonia) or acid (vinegar) based products you not only risk damaging the silvered backing of the mirror, but also tend to leave behind streaks and smears.

DO NOT use ammonia-based cleaning products such as glass cleaner. These may erode the mirror's silver backing. Be sure to read the label of any such cleaning products before use.

PROTECTION AGAINST 'BLACK-SPOTTING' - Alkaline, acid and moisture elements can cause the silvered backing of a mirror to darken, this is usually referred to as 'black-spotting'. An easy way to protect your mirror against black-spotting is to regularly oil any exposed edges (i.e. polished or bevelled edges), using non-petroleum based oils (eg. sewing machine oil). This will act as a seal to protect against such elements. Always remember to keep your mirror dry and wipe off any water, moisture or steam.

Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

Don't risk it, use a licensed plumber.™

