

## Posh Solus Basin Top Assembly (Pair)

### Important Note

Tapware must be installed to the requirements of AS/NZS 3500 by a qualified plumber. Please ensure all pipework is thoroughly flushed out prior to installation.

### INSTALLATION

1. Fully open tap spindle, ensure fibre washer and jumper valve are in position
2. Screw spindle and stuffing box into recess tap body by hand and tighten with suitable tube spanner
3. Place flange over spindle and stuffing box and tighten firmly by hand
4. Fit handle assembly as follows:
  - i. Turn both spindles to the fully closed position
  - ii. Place handle retaining nut over spindle, with slot facing down
  - iii. Place handle retaining clip into groove at bottom of spline in spindle
  - iv. Fit handle to spindle in desired position. Align handle retaining nut
  - v. Screw retaining nut upwards into handle and tighten using spanner provided

