

# KADO

## Kado Neue Oval Semi Inset Basin No Taphole 560mm

9507345

### INSTALLATION INSTRUCTIONS

1. Cut hole in benchtop, as per template supplied with product.
2. Fit Selected waste to Basin. Ensure waste is sealed top and bottom.
3. Apply waterproof sealant (not supplied) to the rim of the Basin and to the bench top.
4. Fit Basin onto the Bench Top and press firmly all around to achieve a good seal.
5. Remove surplus sealant.

#### Note

- If wall mounted tapware is to be used, consideration should be made to length and height of outlet and position of basin on the benchtop.
- If tapware is to be bench mounted allow suitable benchtop width for fitting tapware.