

Kado Era Exposed Shower & Bath Set Lever Porcelain Handle

**IMPORTANT INFORMATION: please read before starting installation.
A Licensed Plumber must install this product.**

1. It is the plumber's responsibility to ensure that all assembled components and threaded joints are checked for correct assembly prior to installing.
2. All threaded joints are to be taped with suitable plumbers tape or sealed with a recommended sealing compound.
3. Prior to installation, the tapware must be pressure tested using the appropriate testing equipment.
4. Prior to installation, the installer is responsible for ensuring installation of the correct plumbing fittings and the set out distances are correct for the product supplied.

