

Mizu Bloc MK2 Handshower with Wall Bracket 1 Function (3 Star)

INSTALLATION INSTRUCTIONS:

1. Ensure exposed thread on the male water connection is cleaned. Apply thread sealing tape or a thread sealing compound to the threads
2. Fit wall lug adaptor (4) to male water connection on wall. Use a 10mm allen key to tighten the adaptor fully
3. Fit the wall bracket (6) onto the wall lug adaptor and secure by tightening two set screws (7) at the bottom of the bracket with a 2.5mm allen key
4. Fit short connection end of the handshower hose (11) to the bottom water outlet (10) on the wall bracket. Fit other hose connection end to the handshower (18)
5. Place handshower firmly inside the handshower holder (15) on the wall bracket
6. Operate handshower and check for leaks

CLEANING RECOMMENDATIONS:

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions