

### Posh Solus Wall Top Assembly (Pair)

#### Important Note

Tapware must be installed to the requirements of AS/NZS 3500 by a qualified plumber. Please ensure all pipework is thoroughly flushed out prior to installation.

#### INSTALLATION

1. Fully open tap spindle, ensure fibre washer and jumper valve are in position.
  2. Screw spindle and stuffing box into recess tap body by hand and tighten with suitable tube spanner.
  3. Place flange over spindle and stuffing box and tighten firmly by hand.
  4. Fit handle assembly as follows:-
    - i) Turn both spindles to the fully off position.
    - ii) Place the handle retaining nut over the spindle with the slot facing the wall.
    - iii) Place the handle retaining clip into the groove at the bottom of the spline of the spindle.
    - iv) Fit handle to spindle and position to suit. Push the handle down firmly until it bottoms internally.
    - v) Screw retaining nut into the handle and tighten using the spanner provided.
- NOTE: Adaptors may be required for extension of spindle where recess of body is beyond plaster or tile

