

Posh Solus Washing Machine Stops (Pair)

Important Note

Tapware must be installed to the requirements of AS/NZS3500 by a qualified plumber. Please ensure all pipework is thoroughly flushed out prior to installation.

INSTALLATION

1. Check the threaded nipple is the correct length. Apply sealant eg thread tape to the thread.
2. Place the cover plate over the threaded nipple and screw the tap body onto the threaded nipple. Position as required ensuring you dont over tighten.
3. Fit handle assembly as follows:-
 - i) Turn both spindles to the fully off position.
 - ii) Place the handle retaining nut over the spindle with the slot facing the wall.
 - iii) Place the handle retaining clip into the groove at the bottom of the spline of the spindle.
 - iv) Fit handle to spindle and position to suit. Push the handle down firmly until it bottoms internally.
 - v) Screw retaining nut into the handle and tighten using the spanner provided.

