




LAUFEN KARTELL DISC BASIN MIXER



Troubleshooting

Change cartridge



Change aerator

