


Commercial gas Storage Model 624265 Interior 265L

Launched July 2020





Spare Parts Manual

Commercial gas Storage Model 624265 Interior 265L

Launched July 2020


Item	Part N°	Description	
1	108113	Draught Diverter	
2	101217-1	Jacket Top	
3	221909	Anode	Black
	221924		Blue
	222014		Green
4	108158-1	Jacket Bottom	
5	108411	Cover Top Indoor LCM	
6	108410	Cover Base LCM	
7	108189	Flue baffle	
8	108243	Bracket Handgrip	
9	221735	Cover Foam	
10	221406-1	Pipe Seal – Inlet & Outlet	
11	221358-1	Pipe Seal – TPR & Drain	
12	057343	Cover Sensor 70mm	
13	220511	Dip Tube 1¼” 190 Long Ryton	
14	229460	Fitting Liner (¾” Noryl)	
15	080147	Fitting Brass Plug ¾	
16	079427	Adaptor – Temperature Sensor Probe	
17	890280	Temperature Sensor set	
18	108607	Heat Shield - 265L	
19	108258	Clamp plate – sight glass	
	088205	Rivet 3.2Dia	
20	080016	Window Insert	
21	087016	Gasket – Viewing window	
22	220604	Valve T&PR ¾ x 1000 HTE715/717	
23	229450	Fitting Liner - Inlet	
24	108107	Foot	
25	120806	Namestrip 260 - 275	
26	087068	Seal Edge	

Commercial gas Storage

Model 634265

Exterior 265L

Launched July 2020





Spare Parts Manual

Commercial gas Storage

Model 634265

Exterior 265L

Launched July 2020


Item	Part N°	Description	
1	108422	Flue Terminal Assy	
2	101217-1	Jacket Top	
3	221909	Anode	Black
	221924		Blue
	222014		Green
4	108158-1	Jacket Bottom	
5	108298	Air Duct	
6	108099	Cover Top Outdoor LCM	
7	108410	Cover Base LCM	
8	108243	Bracket Handgrip	
9	221735	Cover Foam	
10	221406-1	Pipe Seal – Inlet & Outlet	
11	221358-1	Pipe Seal – TPR & Drain	
12	057343	Cover Sensor	
13	220511	Dip Tube 1¼” 190 Long Ryton	
14	229460	Fitting Liner (¾” Noryl)	
15	080147	Fitting Brass Plug ¾	
16	079427	Adaptor – Temperature Sensor Probe	
17	890280	Temperature Sensor set	
18	108607	Heat Shield - 265L	
19	108258	Clamp plate – sight glass	
	088205	Rivet 3.2Dia	
20	080016	Window Insert	
21	087016	Gasket – Viewing window	
22	220604	Valve T&PR ¾ x 1000 HTE715/717	
23	229450	Fitting Liner - Inlet	
24	108107	Foot	
25	120806	Namestrip 260 - 275	
26	087068	Seal Edge	

Commercial gas Storage

Model 624275

Interior 275L

Launched July 2020





Spare Parts Manual

Commercial gas Storage Model 624275 Interior 275L

Launched July 2020


Item	Part N°	Description	
1	108145	Draught diverter	
2	101217-1	Jacket Top	
3	221909	Anode	Black
	221924		Blue
	222014		Green
4	108152-1	Jacket Bottom	
5	108411	Cover Top Indoor LCM	
6	108410	Cover Base LCM	
7	108282	Flue Baffle	
8	108243	Bracket Handgrip	
9	221735	Cover Foam	
10	221406-1	Pipe Seal – Inlet & Outlet	
11	221358-1	Pipe Seal – TPR & Drain	
12	057343	Cover Sensor	
13	220511	Dip Tube 1¼" 190 Long Ryton	
14	229460	Fitting Liner (¾" Noryl)	
15	080147	Fitting Brass Plug ¾	
16	079427	Adaptor – Temperature Sensor Probe	
17	890280	Temperature Sensor set	
18	108603	Heat Shield - 275L	
19	108258	Clamp plate – sight glass	
	088205	Rivet 3.2Dia	
20	080016	Window Insert	
21	087016	Gasket – Viewing window	
22	147502	Draught diverter adapter	
23	053045	Flue damper complete	
	890160	Flue damper actuator	
24	220604	Valve T&PR ¾ x 1000 HTE715/717	
25	229450	Fitting Liner - Inlet	
26	108107	Foot	
27	120806	Namestrip 260 - 275	
28	087068	Seal Edge	

Commercial gas Storage

Model 634275

Exterior 275L

Launched July 2020





Spare Parts Manual


Commercial gas Storage Model 634275 Exterior 275L

Launched July 2020

Item	Part N°	Description	
1	108422	Flue Terminal Assy	
2	140316-1	Jacket Top	
3	221909	Anode	Black
	221924		Blue
	222014		Green
4	108152-1	Jacket Bottom	
5	108298	Air Duct	
6	108099	Cover Top Outdoor LCM	
7	108410	Cover Base LCM	
8	108154	Flue Baffle	
9	108243	Bracket Handgrip	
10	221735	Cover Foam	
11	221406-1	Pipe Seal – Inlet & Outlet	
12	221358-1	Pipe Seal – TPR & Drain	
13	057343	Cover Sensor	
14	220511	Dip Tube 1¼" 190 Long Ryton	
15	229460	Fitting Liner (¾" Noryl)	
16	080147	Fitting Brass Plug ¾	
17	079427	Adaptor – Temperature Sensor Probe	
18	890280	Temperature Sensor set	
	051425	Fan Assy (Includes fan motor, pressure switch, capacitor, wiring and brackets)	
19	NA	Capacitor	
20	056061	Fan Motor & Capacitor	
21	108296	Fan Mount Bracket	
24	056060	Switch - Pressure	
25	080288	Grommet	
26	108603	Heat Shield - 275L	
27	108258	Clamp plate – sight glass	
	088205	Rivet 3.2Dia	
28	080016	Window Insert	
29	087016	Gasket – Viewing window	
30	220604	Valve T&PR ¾ x 1000 HTE715/717	
31	229450	Fitting Liner - Inlet	
32	108107	Foot	
33	120806	Namestrip 260 - 275	
34	051427	Fan Inlet Cone	
35	087068	Seal Edge	

Models 624 & 634 - Burner assembly

Launched July 2020





Spare Parts Manual

Models 624 & 634 - Burner assembly

Launched July 2020

Item	265L	275L	Description		
1	140073	140073	Bracket Gas Control Formed		
2	074513	074507	Burner (Without include HSI, Flame Probe & Igniter holder)		
3	051422	051422	Thermostat		
4	051421	051421	Jumper Wire Assy HD Gas (except 624275)		
5	051424	051424	Wiring Assy HD Gas Ctrl to Thst (Includes reset switch, relay & BMS Socket)		
6	053003	053003	Cord clamp		
7	053165	053165	Cable Electric Plug & Earth Terminal Assy		
8	088221	088222	Burner Feed Pipe		
9	051423	051423	Wiring Assy – Includes ECO		
10	079499	079499	Screw Mounting Gas Control		
11	070532	070532	Control H.S.I P25 NV	Indoor	
	070532	070535		Outdoor	
12	080118	080118	Screw Philips Pan 8 x 3/8 "B" Nibb		
13	079500	079500	Gas valve NG – White Rogers		
	079520	079520	Regulator Spring - Propane		
	079530	079530	Regulator Spring - Natural		
14	079506	079506	Test point spigot		
15	079515	079515	Fitting Brass Flared Union 3/4x3/4		
16	145406	145406	Igniter Bracket		
17	070536	070536	H.S.I igniter and flame probe		
18	073324	-	Main burner injector	Natural Gas	4.80
	-	073318		Natural Gas	6.50
	073379	-		Propane Gas	2.90
	-	073378			3.80
19	-	-	Clip Spring Heavy Duty Gas – Part of item 8		
20	-	-	Burner Endplate HD Gas – Part of item 8		
21	56659096	56659096	Reset Switch		
N/S	088012	088012	Rivet		
	051426	NA	Wiring Power Flue Interlock HD Gas		