



■ GEBERIT

SIGMA80 ELECTRONIC BUTTON/ACCESS PLATE



Dimensions are nominal measurements only.




Sigma80 requires power supply installation set 9504026

SPECIFICATIONS

Recommended use	Domestic, hotel and commercial
Material	Glass
Colour Availability	Black, Smoked Reflective
Application	Dual-flush Actuator
Compatibility	Sigma8 Cistern
Operation	Electronic, Hands free
Standby power	<1 watt
Spare Parts	Guarantee of availability for 25 years
Technical Support	1800 Geberit



To see the complete GEBERIT range go to
www.reece.com.au/bathrooms



9504026 Installation set
(Included)



Sigma80 Black Glass
Sigma80 Reflective Glass



1811578
1811579

CLEANING INSTRUCTIONS

You have selected a Geberit product with a high-grade surface. Please follow the cleaning instructions so that your Geberit product will give you many years of pleasure.

Never use aggressive cleaners that contain chlorine, are acidic, abrasive or corrosive.

Only use water and a mild cleaning agent.

1. Clean the unit with a soft cloth soaked in water.

2. Dry with a soft cloth.

Damage caused by any improper treatment is not covered by the product warranty. Refer to warranty Conditions.

Disclaimer: Products in this specification manual must by regulation be installed by licensed and registered trade people. The manufacturer/distributor reserves the right to vary specifications or delete models from their range without prior notification. Dimensions are nominal measurements only. Dimensions and set-outs listed are correct at time of publication however the manufacturer/distributor takes no responsibility for printing errors.

Tech Page – Version 1





■ GEBERIT

reece™


GEBERIT

SIGMA80 ELECTRONIC BUTTON/ACCESS PLATE


INSTALLATION INSTRUCTIONS




3




4



5



6





Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

GEBERIT


SIGMA80 ELECTRONIC BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS


7




9




10



11



12



Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference


GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS


13




14




15




16



17



18




Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference


GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS


19




20




i




21




22



23




2





GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS


24




25




26



27



28





Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE



INSTALLATION INSTRUCTIONS

1




Check sensor activates lights

1




Check lights remain on

2



2




Check half flush

Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS

3



GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS

EN


Intended use:

The installation set with mains transformer is intended to provide a power supply for Geberit WC flush controls.




This product may only be mounted by qualified persons in accordance with EN IEC 62079:2001.







Connect the all-pole power switch in series with at least 3 mm contact opening.

GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE**INSTALLATION INSTRUCTIONS**

Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE**INSTALLATION INSTRUCTIONS**

Ø 76 mm




Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference


GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS

A1



A2




Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference


GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE

INSTALLATION INSTRUCTIONS


B1



B2



Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE**INSTALLATION INSTRUCTIONS**

Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

GEBERIT
SIGMA80 ELECTRONIC
BUTTON/ACCESS PLATE**INSTALLATION INSTRUCTIONS**