



Key Parameters:

/IE = 2 Enable ambient probe S1 on external display
 St = Setpoint
 rd = Differential
 F2 = 0 Fans cycle with compressor (0=no, 1=yes)

Parts Required:

DN33C0HR00 Din rail mount controller
 IR00XGD000 Remote display
 PSTCON03B0 Connecting cable
 IROPZSER30 Remote display interface