



Memo Harper Sinks - Fine Fireclay

FIRECLAY SINKS - CARE AND MAINTENANCE INSTRUCTIONS

To maintain the original appearance, it is important to do a regular clean with non-abrasive cleaners and a soft sponge.

Fireclay sinks are created by firing the clay at high temperatures therefore some visual distortion may occur. This is not a defect but can be seen to add to the beauty of the product.

Water Stains

Use a low concentration of vinegar to remove hard water stains. Rinse well after. Keeping the sink dry will avoid future water stains.

General Stains

Marks and stains caused by foods and liquids should be removed immediately with hot water and gentle cleaning agent. Cleaners, such as Jif, can be used to remove tougher stains.

For more stubborn stains, soak a water and detergent mixture overnight, scrub off any dirt and stains, and finally rinse with water.

Light Marks

Metal cutlery and cooking utensils can leave marks on the surface. These can be removed by Bar Keeper's Friend or a similar cleaner.

Scratches

Fireclay is extremely durable and long lasting. However, if scratches and chips do occur, Cramer Repair Kit is recommended for minor damages to the sink.

Do Not Use

Fireclay sinks can withstand many chemical cleaning agents; however, it can cause damage to the wastes and taps. **Below is not advised.**

- Steel wool, scourers or metal brush to sink
- Harsh cleaners containing severe acidic or alkaline chemicals such as sodium hydroxide, sulfuric acid or hydrochloric acid
- Toilet cleaners such as Chlorinated Cleansers or bleach of any type

Note

Damage caused by any improper treatment is not covered by the product warranty – refer to Warranty Conditions.

Plumbers, please ensure a copy of the Installation Instructions are left with the end user for future reference

