



Tapware Installation Instructions

FOR THE PLUMBER:

1. All work should be carried out by a licensed plumber. Responsibility will not be accepted for incorrect installation of this tapware, or any tapware not installed by a Registered Plumber.
2. The water supply lines need to be 'flushed out' prior to installation. This will avoid any foreign materials blocking the flow regulator, damaging the cartridge and reducing the flow of water.
3. Sink and Basin Mixers require flexible hoses. These flexible hoses are supplied and marked with red and blue, denoting hot and cold. The hoses are fitting to hot and cold water inlet respectively.
4. Place the rubber seal on the underside of the base ring. Screw the flexible hoses (2) firmly into the Mixer, being careful not to kink the flexible hoses.
5. Screw on the mounting stud to the underside of the Mixer and tighten with a phillips head screwdriver.
6. Place the Mixer in the allocated hole of your sink or vanity with the flexible hoses going in first.
7. From underneath the bench top, fit the base washer, base plate and fixing nut in the respective order.
8. Tighten the fixing nut to clamp the mixer onto the sink or vanity. Ensure the Mixer is attached firmly.
9. FLUSH THE TWO PIPELINES TO CLEAR DEBRIS. Connect the Mixer to the water supply line by connecting the two flexible hoses to the isolating stop valve.

Maximum working pressure 500kPa Minimum working pressure 50kPa

***If water pressure exceeds 500kpa a plumber must install a pressure limiting valve to the isolating stop valves ***

PRODUCT WARRANTY:

Your Milli Mixer carries a one year manufacturers warranty and a five year cartridge warranty from the date of purchase.

Providing-

1. The original sales receipt is to be provided as proof of purchase. The warranty is extended to the purchaser only and is not transferable.
2. The Mixer must be installed by a Licensed Plumber (proof of receipt).
3. All new connections must be flushed prior to the connection of the flexible hoses to the isolating valves.
4. If water pressure exceeds 500kPa, an approved pressure limiting valve must be fitted.
5. Do not use abrasive cleaners or any scouring cloth/pad to clean the product as it will scratch the surface. The surface of the Mixer should be cleaned only with warm water and mild detergent.
6. Due to large amounts of impurities in the water, regular cleaning or replacement of approved aerators is recommended.
7. Product has been used for its intended application.
8. No additional devices have been fitted to the Mixer – eg water filters.
9. Where a product has been installed and a manufacturing fault is claimed, Bastow will arrange for a Service Call to correct the fault.

FAILURE TO COMPLY WITH THE PRODUCT WARRANTY WILL VOID ALL WARRANTY AGREEMENTS

REPLACEMENT OF MIXER CARTRIDGE:

Remove the grub screw in the lever handle and lift off the handle. Unscrew the dome cap and the lock nut. Lift out the old cartridge and clean inside the outer casing. Insert new cartridge ensuring the lungs on the bottom of the cartridge line up with the holes in the mixer main body. Assemble fixing nut (tighten with a spanner), the dome cap and the handle securely.

Plumbers, please ensure a copy of the installation instructions is left with the end user for future reference

