

## mız.u

## Soothe MK2 Floor Mounted Bath Mixer Kit


1. Prior to installation, please check if all the parts are complete.




3. Connect the pipes with concealed box and then open the water supply to check if there is leakage.




5. Make sure the concealed box is perfectly horizontal and then lock it up with expansion screws.




2. Cut slots according to the diagram below, note the depth includes tiles' thickness.



4. According to diagram below, drill 4 holes of 10mm on the ground. Then fit the expansion screws into the holes.




6. Put on the upper cover and tile the floor.




## Soothe MK2 Floor Mounted Bath Mixer Kit

7. Take off the upper cover, M5 screws, washers, flange and testing plug. Carefully keep them for later use.




8. Use a saw or knife to cut off the unwanted part of the plastic sleeve, so that the box is flush with the floor.



9. Grease the spout end with silicone oil and then connect it with the valve body. Insert the valve body through the base plate and then secure the flange to the bottom of valve body with M4 screws. 10. Grease the bottom of valve assembly with silicone oil and then connect it with the concealed box with M5 screws.

11. Installation completed.



## **Care Details**

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty - refer to Warranty Conditions on the last page.

Plumbers, please ensure a copy of the installation instruction is left with the end user for future reference.

