


**Note:** EVD Ice DI Input is N/A with Comms Connected.

Power  
230VAC

## CaberoPRO CH Evaporator



**Application Guide:**  
Ultracella Medium Temp,  
CaberoPRO CH,  
with 500mm Fans

**CAREL**

Phone 02-8762 9200  
Email cst.au@carel.com

Drawn by: BF Date: 01/03/2018

Checked by: PV Date: 08/03/2018

Part number

WB000DG0F0

NTC030HP03

PGDEWB0FZK

+0300083EN

Description

UltraCella double display, revision 2.0


Carel NTC temperature sensor, 3m

Ultracella service pGD tool

UltraCella user manual

Drawing: Ultracella\_MT\_CH\_CaberoPRO\_500mm\_Fans


Rev: 2.0



Ultracella Parameters	
<b>1. Probes (PRO)</b>	<b>10. Door &amp; Lights (doL)</b>
/t2 = 21 Display Superheat	A3 = Disable door switch 1 = Disabled
/A2 = 0 Disable defrost probe B2	<b>14. EVD ICE (ICE) *</b>
<b>2. Control (CtL)</b>	IPE = 1 Enable EVDice Driver
St = Setpoint	PH = Refrigerant type ** 1 = R22, 2 = R134a 3 = R404A, 4 = R407c, 11 = R744
rd = Differential	tr1 = Enable temperature data logging. 3 = Regulation probe
<b>4. Defrost (dEF)</b>	IrE = 1 EEV Application (Cold Room)
d0 = Defrost type 2 = electric/time	IP3 = 6 Superheat Setpoint
dl = Defrost intervals (hrs)	IS1 = 3 Pressure sensor used (3 = standard supply -1.0 to 9.3 bar)
dP1 = Max defrost duration (min)	IC1 = 2K Low superheat threshold
<b>5. Alarm (ALM)</b>	IC3 = L.O.P. set as SST Coolroom set as -12 Freezer set as -35
A1 = Alarm type 0 = relative, 1 = absolute	IC5 = 15 M.O.P. set as SST
AL = Alarm low threshold	IIA = 1 Disable operation mode on EVD Ice (1 = Disable, recommended)
AH = Alarm High threshold	IU4 = 40% Valve opening position on start up
Ad = Alarm delay (min)	ICG = 1 Enable EVD Ice regulation
<b>6. Evaporator Fan (Fan)</b>	
F0 = Fan management 4 = Fan always On	
<b>7. Configuration (CnF)</b>	
H0 = Serial address	
H1 = 1 Aux 1 Alarm Output	
tr1 = Enable temperature data logging. 3 = Regulation probe	
trc = Sample time for recording (min)	

\* Once connected to the EVD Ice via communication, it is not necessary to set any parameters at the EVD Ice itself. It can be programmed at the Ultracella.

\*\* Refer to the manual for full refrigerant selections



**Comissioning Tool:**  
PGDEWB0FZK



**How to retrieve the data log with USB:**

1/ Insert a USB into the Ultracella

2/ Press 'PRG' and 'Set' until the display shows 'HcP', then scroll to 'LoG'.

3/ Press 'Set' to confirm the download, the display will flash 'LoG' during the download.

4/ Press 'PRG' until you exit the menu, remove the USB.

**CAREL**

Phone 02-8762 9200  
Email cst.au@carel.com

Drawn by: BF Date: 01/03/2018

Checked by: PV Date: 08/03/2018

Part number

WB000DG0F0

NTC030HP03

PGDEWB0FZK

+0300083EN

Description

UltraCella double display

Carel NTC temperature sensor, 3m

Ultracella service pGD tool

UltraCella user manual

Drawing: Ultracella\_MT\_CH\_CaberoPRO\_500mm\_Fans

Rev: 2.0

