


mizu

Drift Shower Handpiece 2 Function Spray (5 Star)



Shower Kit Installation



The Mizu Drift comes to you already factory assembled and tested. We do not recommend the dismantling of any internal part of the product. The Mizu Drift is tested and sealed so as to give the best performance.




When water pressure is in excess of 500kPa a pressure limiting device is required in accordance with 'AS/NZS 3500.1' recommendation.



This shower may not be suitable for use with gravity fed water heaters and water supply networks with low and unequal pressure.

Installation

1. Screw handpiece onto shower hose in anticlockwise direction.
2. Ensure sealing washer supplied with shower hose is placed between hose and handpiece. Tighten firmly and align correctly onto handpiece holder / slider.
3. Turn on water supply and check for any leaks.



Care Details

We recommend the use of soapy water or approved cleaners. This product should not be cleaned with abrasive materials. Damage caused by any improper treatment is not covered by the product warranty - refer to Warranty Conditions on the last page.

Plumbers, please ensure a copy of the installation instruction is left with the end user for future reference.

