


# FRANKE

## DESIGNER T-SHAPE CANOPY RANGEHOOD 90CM



Dimensions are nominal measurements only.

### SPECIFICATIONS

Recommended use	Domestic
Material	Stainless Steel
Colour availability	Stainless Steel
Weight	20kg
Dimensions	898 x 470 x 775-1045mm
Width	900mm
Voltage	220-240V / 50Hz
Air Flow	690 m3/h
Noise level (dBa)	54
Lighting	LED 2x1W
Plug	Plug with 3 pins
Switch	Soft touch control
Fan Speeds	3
Filter	Multi-layer stainless steel mesh
Power cord length	1000mm



To see the complete FRANKE range go to  
[www.reece.com.au/bathrooms](http://www.reece.com.au/bathrooms)

### CLEANING RECOMMENDATIONS

We recommend the use of soapy water or approved cleaners.

This product should not be cleaned with abrasive materials.

Damage caused by any improper treatment is not covered by the product warranty. Refer to Warranty Conditions.

# FRANKE


## DESIGNER T-SHAPE CANOPY RANGEHOOD 90CM

### INSTALLATION INSTRUCTIONS

#### WALL DRILLING AND BRACKET FIXING


Wall marking:

- Draw a vertical line on the supporting wall up to the ceiling, or as high as practical, at the centre of the area in which the hood will be installed.
- Draw a horizontal line at 650 mm above the hob.
- Place bracket 7.2.1 on the wall as shown about 1-2 mm from the ceiling or upper limit aligning the centre (notch) with the vertical reference line.
- Mark the wall at the centres of the holes in the bracket.
- Place bracket 7.2.1 on the wall as shown at X mm below the first bracket (X = height of the upper chimney section supplied), aligning the centre (notch) with the vertical reference line.
- Mark the wall at the centres of the holes in the bracket.
- Mark a reference point as indicated at 116 mm from the vertical reference line and 305 mm above the horizontal reference line.
- Repeat this operation on the other side.
- Drill  $\varnothing$  8 mm holes at all the centre points marked.
- Insert the wall plugs 11 in the holes.
- Fix the lower bracket 7.2.1 using the 12a screws (4,2 x 44,4) supplied.
- Fix the upper bracket 7.2.1 and the air outlet connection support 7.3 together using the 2 screws 12a (4,2 x 44,4) supplied.
- Insert the two screws 12a (4,2 x 44,4) supplied in the hood body fixing holes, leaving a gap of 5-6 mm between the wall and the head of the screw.



#### MOUNTING THE HOOD BODY

- Before attaching the hood body, tighten the two screws Vr located on the hood body mounting points.
- Hook the hood body onto the screws 12a.
- Fully tighten the support screws 12a.
- Adjust the screws Vr to level the hood body.




#### CONNECTIONS

##### DUCTED VERSION AIR EXHAUST SYSTEM

When installing the ducted version, connect the hood to the chimney using either a flexible or rigid pipe  $\varnothing$  150 or 120 mm, the choice of which is left to the installer.

- To install a  $\varnothing$  120 mm air exhaust connection, insert the reducer flange 9 on the hood body outlet.
- Fix the pipe in position using sufficient pipe clamps (not supplied).
- Remove any activated charcoal filters.




# FRANKE

## DESIGNER T-SHAPE CANOPY RANGEHOOD 90CM

### INSTALLATION INSTRUCTIONS


#### RECIRCULATION VERSION AIR OUTLET

- Insert the connection extension pieces laterally 14.1 in connection 15.
- Insert the Connector 15 into the Support bracket 7.3 and fix it with a screw.
- Make sure that the outlet of the extension pieces 14.1 is horizontally and vertically aligned with the chimney outlets.
- Connect the air outlet connection 15 to the hood body outlet using either a flexible or rigid pipe  $\varnothing$  150 mm, the choice of which is left to the installer.
- Ensure that the activated charcoal filters have been inserted.




#### ELECTRICAL CONNECTION

- Connect the hood to the mains through a two-pole switch having a contact gap of at least 3 mm.
- Remove the grease filters (see paragraph Maintenance) being sure that the connector of the feeding cable is correctly inserted in the socket placed on the side of the fan.



#### FLUE ASSEMBLY



##### **Upper exhaust flue**

- Slightly widen the two sides of the upper flue and hook them behind the brackets 7.2.1, making sure that they are well seated.
- Secure the sides to the brackets by using the 4 screws 12c (2,9 x 9,5) supplied.
- Make sure that the outlet of the extensions pieces is aligned with the chimney outlets.

##### **Lower exhaust flue**

- Slightly widen the two sides of the flue and hook them between the upper flue and the wall, making sure that they are well seated.
- Fix the lower part laterally to the hood body by using the 2 screws 12c (2,9 x 9,5) supplied.