

### DROP-IN SYSTEM - STANDARD EVAPORATOR - MODEL 2012/4

#### INSTALLATION INSTRUCTIONS

1. It is essential that there is good ventilation above and around the coolroom to ensure efficient operation.
2. Cut a hole in the roof of the coolroom as shown on the sketch.
3. Fit the rubber seal around the edge of the prepared hole in the roof of the coolroom, for the flange of the unit to seal against. No further fixing necessary.
4. Lower the unit onto the rubber seal with the fan position as shown in the sketch.
5. Push the drain fitting into the rubber connection at the back of the driptray to enable a drain hose to be connected.
6. The drain tube should either be dropped into a container inside or outside the room, with the end under the water level at all times. If a container is not used, the a “P” trap should be fitted or formed at the lowest part of the drain tube to prevent air being drawn up through the tube which will affect both the flow of condensate from the evaporator tray, and system efficiency.
7. Connect to a dedicated 3 pin single phase 15 amp power point. The use of an extension lead is not acceptable.

This pack includes:  
1 x Rubber Seal

#### PLAN VIEW OF COOLROOM

##### MODEL 2012/4 DROP-IN SYSTEM

