



## Basin and Sink Mixer Installation Instructions

### **FOR THE PLUMBER:**

1. All work should be carried out by a Registered plumber. Responsibility will not be accepted for incorrect installation of this tapware, or any tapware not installed by a Registered Plumber.
2. The water supply lines need to be 'flushed out' prior to installation. This will avoid any foreign materials blocking the flow regulator, damaging the cartridge and reducing the flow of water.
3. Sink and Basin Mixers require flexible hoses. These flexible hoses are supplied and marked with red and blue, denoting hot and cold. The hoses are fitting to hot and cold water inlet respectively.
4. Place the rubber seal on the underside of the base ring. Screw the flexible hoses firmly into the Mixer, being careful not to kink the flexible hoses.
5. Screw on the mounting stud to the underside of the Mixer and tighten with a phillips head screwdriver.
6. Place the Mixer in the allocated hole of your sink or vanity with the flexible hoses going in first.
7. From underneath the bench top, fit the base washer, base plate and fixing nut in the respective order.
8. Tighten the fixing nut to clamp the mixer onto the sink or vanity. Ensure the Mixer is attached firmly.
9. FLUSH THE TWO PIPELINES TO CLEAR DEBRIS. Connect the Mixer to the water supply line by connecting the two flexible hoses to the isolating stop valve.

**Maximum working pressure 500kPa Minimum working pressure 50kPa**

**\*If water pressure exceeds 500kpa , plumber must install a pressure limiting valve to the isolating stop valves \***

Responsibility will not be accepted for incorrect installation  
of this Tapware, or any Tapware **not installed by a REGISTERED PLUMBER**

Plumbers, please ensure a copy of the installation  
instructions is left with the end user for future reference.

